



**All Nydree Engineered Flooring Products
Pedestrian UV-Cured Finish
Bona® Prep™ & Recoat Adhesion System
Pedestrian Recoating and Preventative Sealing**

Worn or Lightly Scratched Finish (The Pedestrian finish is not worn through to the wood)

In this case it is not necessary to remove the factory-applied Pedestrian coating to refinish a Nydree Flooring installation. The Bona Prep & Recoat System has been tested and approved for use on all Nydree Flooring (PermaGrain and Gammapar) finished with Pedestrian UV-Cured Finish. Bona's Prep & Recoat System is designed to blend out surface scratches (light scratches in the existing finish only) and scuffs, cover and renew most traffic patterns and provide a beautiful, just-finished appearance. Outlined below is the general Bona Prep & Recoat procedure. A video showing how to refinish flooring using the Bona Prep & Recoat System can be seen at <http://www.bona.com/en-US/United-States1/Movie-Gallery/?movie=16227>.

Newly Installed Nydree Flooring

When Nydree Flooring is used in an environment where there is potential for spills and frequent spot cleaning (restaurants / bars / food service areas) it is recommended that the flooring be completely sealed. The Bona Prep & Recoat Adhesion System can be used on newly installed Nydree Flooring to seal all of the plank edges. Follow the instructions below, but skip step #1 for newly installed flooring. *It is important to note that on newly installed flooring, the UP-28-0VOC installation adhesive must cure for at least 48 hours prior to using the Bona Prep & Recoat System.*

Damaged Finish (Spots of the Pedestrian finish are completely worn away or heavy scratches/gouges)

See Complete Pedestrian/Old Finish Removal and Recoating Procedure under Maintenance Instructions on the Nydree Flooring website.

BONA PREP RECOATING PROCEDURE – FOLLOW MANUFACTURER'S INSTRUCTIONS

IMPORTANT INFORMATION – DO NOT USE the Bona Prep Recoating System over Pedestrian finish that has been waxed, polished, oiled or has been maintained with a commercial coating.

1. Test for paste wax, acrylic floor polishes and acrylic wax.
2. Sweep and vacuum the floor thoroughly to remove any loose dirt and grit.
3. The floor must be cleaned and lightly abraded to ensure that the new coating will adhere.
4. Use Bona Prep as a spray buff solution with a standard low speed (175-250 rpm) buffer and a Bona Conditioning Pad. Spray Bona Prep over a large section of the floor (approximately 3' x 12') at a rate of 2,000 square feet per gallon. For large areas, a string mop can be used to apply the Bona Prep. **NOTE:** Regardless of the size of area, be sure to overlap sections to ensure that no areas are missed.
5. Before spray buffing the next section, **REMOVE ALL RESIDUES IMMEDIATELY**, using a Bona Microfiber Mop dampened with Bona Prep.
6. Abrade the floor once it has dried using two Bona Conditioning Pads (one driving the other). Any visibly unabraded areas should be cleaned and abraded by hand.
7. Tack the floor again to remove dust using a Bona Mop or a wrung-out cotton towel or cloth dampened with Bona Prep.
8. Allow the floor to dry completely. Within 2 hrs. of Bona Prep drying, apply Bona Traffic® or Bona Traffic HD™. Satin matches the original factory finish of Nydree (PermaGrain and Gammapar) flooring (Effective Oct.2011), but any gloss level may be used. After the initial coat of Bona Traffic or Traffic HD is dry (approximately 2-3 hours) a second coat must be applied. For smoothest results, abrade with a Bona Conditioning Pad before applying second coat. Always vacuum and tack thoroughly with a slightly water-dampened Bona Microfiber Mop or cloth after abrading. A third coat of finish is recommended in heavy-traffic commercial areas. Twenty-four hours after applying the last coat of finish, the floor can be walked on, but remains susceptible to scuffing or marring for a period of one week.
9. The new finish can be maintained with Bona Pro Hardwood Floor Cleaner and Nydree Dust Mop Treatment one week after the Bona Traffic or Traffic HD floor finish has been applied. Rugs can also be replaced at this time.

Any of the Bona System products can be purchased through Nydree Flooring Customer Service by calling 800.682.5698.

Bona® Prep™, Traffic® and Traffic HD™ are registered trademarks of BonaKemi USA, Inc.
© 2011 Nydree Flooring, LLC

10/11