

Splines (slip tongues) are commonly used to 'lock-in' patterned floors/borders and also to reverse the direction of flooring within an installation. During installation, splines will prevent overwood as the flooring adhesive cures. The splines will prevent plank from moving up and down.

After a cut has been made, the plank must be regrooved to accept a spline. Three wing slot cutters with a cut height of 1/8" used in conjunction with a router table work well. Use the router table fence to set the depth of cut equal to the depth of an existing plank groove. The splines (0.112" Thick x 0.280" Wide x 24" Long) for the slip tongue are available and can be glued in place with carpenter's glue. Contact customer service at 800.682.5698 for splines.