

Masking Light Scratches

A Zenith Tibet Almond Stick can be used to make 'white' scratches turn clear.

1. Open canister and remove blue wrapper from Almond stick.
2. Wipe the 'white' scratch **only** with either end of the Zenith Tibet Almond Stick.
3. Wipe any excess off with white rag or Nydree Pedestrian Finish Cleaner and white rag.

Scratch Removal From a Small Area or Individual Plank

1. Be sure the floor is free from wax or oily residue.
2. Sweep and vacuum the damaged area.
3. Clean the plank(s) to be repaired using Nydree Pedestrian Urethane Finish Cleaner.
4. Tape off the damaged plank(s) using 3M™ Painters' Pre-Taped Masking Film or 3M™ 2080 Blue Painter's Tape to avoid coating adjacent planks.
5. Use the 220-240 grit sandpaper to smooth out the scratch in the plank(s). Always sand in the grain direction. Be careful not to completely sand through the finish. Lightly abrade the remainder of the plank(s), so the Touch-Up polyurethane will adhere.
6. Vacuum and tack the plank(s) to remove dust and grit. Clean the planks thoroughly using Nydree Pedestrian Urethane Finish Cleaner and a white rag.
7. Immediately apply 1-2 coats of Nydree Flooring Touch-Up polyurethane to the entire plank(s) using a sponge brush. Allow at least one hour between coats of polyurethane.
8. Abrade with 220-240 grit sandpaper, vacuum and tack with Nydree Flooring Urethane Finish Cleaner-dampened cloth between coats of polyurethane.
9. Remove blue tape.
10. Allow 24 hours for light traffic.

3M™ is a trademark of 3M Industries.

To purchase all Nydree Flooring maintenance products, contact your local sales representative, order maintenance materials from the website www.nydreeflooring.com or call Nydree Flooring Customer Service at 800.682.5698.

3M™ is a trademark of 3M Industries.

© 2010 Nydree Flooring, LLC

05/10