

Masking Light Scratches

A Zenith Tibet Almond Stick can be used to make 'white' scratches turn clear.

1. Open canister and remove blue wrapper from Almond stick.
2. Wipe the 'white' scratch **only** with either end of the Zenith Tibet Almond Stick.
3. Wipe any excess off with white rag.

Superficial Scratch Removal From a Small Area or Individual Plank

1. Be sure the area to be repaired is free from wax, polish or oily residue.
2. Sweep and vacuum the damaged area thoroughly to remove any loose dirt and grit.
3. Tape off the damaged plank(s) using 3M™ Painters' Pre-Taped Masking Film or 3M 2080 Blue Painter's Tape to avoid coating adjacent plank(s).
4. Spray Bona® Prep™ over the flooring to be recoated. Abrade/Buf the flooring wet using the Bona Conditioning Pad (Maroon Pad).
5. Immediately remove any residues using a white rag dampened with Bona Prep.
6. Once the flooring has dried, smooth out the superficial scratches in the plank(s) always sanding in the grain direction using the 220/240 grit sandpaper. Be careful not to completely sand through the finish.
7. Lightly abrade the remainder of the plank(s) using the Bona Conditioning Pad (Maroon Pad), so the Touch-Up polyurethane will adhere.
8. Tack the plank(s) to remove dust and grit using a white rag dampened with Bona Prep.
9. Allow the flooring to dry completely. Immediately apply 2-3 coats of Nydree Flooring Satin Touch-Up polyurethane to the entire plank(s) using a sponge brush. Allow two to three hours between coats of polyurethane.
10. For the smoothest appearance, abrade with the Bona Conditioning Pad (Maroon Pad) and tack with a slightly water-dampened white cloth between coats of urethane.
11. Remove blue tape.
12. Allow 24 hours for light traffic.

*Note: This procedure and kit is for Nydree's standard Pedestrian **Satin** Finish. If a custom gloss finish was applied at the factory, the corresponding gloss finish should be used for the repair.*

To purchase all Nydree Flooring maintenance products, contact your local sales representative, order maintenance materials from the website www.nydreeflooring.com or call Nydree Flooring Customer Service at 800.682.5698.

3M® is a registered trademark of 3M Industries.
Bona® is a registered trademark of BonaKemi USA, Inc.
Prep™ is a trademark of BonaKemi USA, Inc.